



## Remote Console Manager with GSM Modem QS Guide

## **Quick Start Guide**

This Quick Start Guide helps you through installation, configuration, and local operation. For more details, refer to the user manual.



Customer Support Information Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500) FREE technical support 24 hours a day, 7 days a week: Call 724-746-5500 or fax 724-746-0746 • Mailing address: Black Box Corporation, 1000 Park Drive, Lawrence, PA 15055-1018 • Web site: www.blackbox.com • E-mail: info@blackbox.com

## Trademarks Used in this Manual

Black Box and the Double Diamond logo are registered trademarks of BB Technologies, Inc.

Cisco is a registered trademark of Cisco Technology, Inc.

Linux is a registered trademark of Linus Torvalds.

Nagios is a registered trademark of Nagios Enterprises.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

Follow the steps listed below to get started:

Step 1: Check kit contents.

- LES1204A-3G-R2 Remote Console Manager
- This printed quick start guide
- (2) UTP cables
- (1) DB9F-RJ-45 adapter straight-pinned
- (1) DB9F-RJ-45 adapter crossover-pinned
- (1) RF antenna with bracket mount and 1-ft. (30-cm) cable
- Universal input 12-VDC power pack

NOTE: To download the user manual, visit the Black Box Web site and enter LES1204A-3G-R2 in the search bar.

Step 2: Connect the hardware.

NOTE: The LES1204A-3G-R2 Remote Console Manager has an internal 3G GSM cellular modem. Your carrier will provide you with a SIM card to activate your GSM cellular modem plan. The SIM card must be installed in the Remote Console Manager before applying power.

- Unscrew the SIM card access panel on the side of the Remote Console Manager and insert the SIM card with contacts facing upward. The SIM card will lock into place. You may use the tip of the RF antenna to fully seat the SIM card. Replace the SIM card access panel.
- Attach the RF antenna using the cable to the Remote Console Manager.
- Connect your serial devices to the four *SERIAL* ports. The RJ-45 serial connectors have *Cisco*® serial pinouts:



Figure 1. Cisco serial pinouts.

• Connect the LAN port to your network.

 Plug the power pack into the AC power receptacle and connect the DC power cable to the Remote Console Manager's 9-12 VDC power socket.

NOTE: On applying power, the "SIM" LED on top of the Remote Console Manager will go on solid, indicating that the SIM has been inserted and detected.

Step 3: Set up the Remote Console Manager.

The default Remote Console Manager IP address is 192.168.0.1 (subnet mask 255.255.255.0). With a Web browser on any computer that is connected through the LAN to the serial device server:

• Enter https://192.168.0.1 into the address bar.

NOTE: The LAN-connected computer must have an IP address in the same network range (192.168.0.xxx) as the Remote Console Manager. If this is not convenient, you can use the ARP Ping command to set the IP address (refer to the user manual for details). The Remote Console Manager also has its DHCP client enabled by default, so it will automatically accept any network IP address assigned by any DHCP server on your network—and will then respond at both 192.168.0.1 and its DHCP address.

- Log in using the default system user name: root, and the default password: default. A Welcome screen listing the basic configuration steps is displayed.
- Select "Change the default administration password on the Users page," enter and confirm a new password for root, and click "Apply."

BLACK	BOX	System Name: NR3-Hes 15083 Model: LES1508A Firmware: 3.5.3u5 Uptime: 1 days, 1 hours, 19 mins, 20 secs. Current User: root Backup Log Out
		Serial & Network: Users & Groups
Serial & Network 😑	Edit an Existing User	
Serial Port     Users & Groups     Authentication	Username	root A unique name for the user.
Network Hosts     Trusted Networks     Call Home     Cassaded Botts	Description	Root User A brief description of the user's role.
Cascaded Pons     UPS Connections     RPC Connections     Environmental     Managed Devices	Password	The users authentication secret. Note: A password may not be required if remote authentication is being used.
Alerts & Logging	Confirm	Re-enter the users password for confirmation
* Port Log * Auto-Response SSH Au * SMTP & SMS * SNMP	SSH Authorized Keys	
System 🗉		
Administration     SSL Certificates     Configuration Backup     Firmware     P     Date & Time     Date & Time     Data     Firewall     Services     Nagios     Configure Dashboard		Paste the public keys of authorized public/private keypairs to allow pass-key authentication for this user This is more secure than password based authentication
	Disable Password Authentication	Check to only allow public key authentication for this user when using SSH
	Save Password across firmware erases	C Check to save the password hash in the non-volatile configuration partition, which does not get erased on firmware reset. Note: This password is lost, the device will need to be firmware recovered
Status	Apply	

Figure 2. Serial & Network: User & Groups screen.

- To assign your Remote Console Manager a static IP address or to permanently enable DHCP, select "System: IP" then "Network Interface" and check "DHCP" or "Static" for configuration method.
- By default, only HTTPS and SSH access is enabled to the Remote Console Manager itself. Use Service Access menu on System: Services to change this, and to change access privileges for connected serial and network devices.

BLACK			System Name Uptin	:RR3-les1508a Mo ne:1 days,1 hours,3	ndet:LES1508A Firm 89 mins,1 secs Cur	nware: 3.5.3u5 rrent User: root	Backup Log Out
						Syster	
Serial & Network     Serial Port  Serial Port  Serial Port  Anthree Content  Trustee Network  Cascade Ports  Cascade Ports  Cascade Ports  Cascade Ports  Anthree Content  Network  Anthree Content  Anthree Content  Anthree Content  Cascade Ports  Anthree Content  Anthree Content  Cascade Ports  Anthree Content  Anthree Content  Cascade Ports  Anthree Content  Anthree Content  Anthree Content  Anthree Content  Anthree Content  Anthree Content  Cascade Ports  Anthree Content  Anth		Service Settin	igs		Servi	ice Access	
	Services	Service Enabled	Network	Management LAN	Dialout/Cellular	Dial-in	VPN
	HTTP Web Management	Enabled					
	HTTPS Web Management	Enabled	V	N	<b>v</b>	2	N
	Telnet command shell	Enabled					
	SSH command shell	Enabled	V	¥	<b>V</b>	<b>v</b>	M
	Telnet direct to serial ports	N/A	V	¥		শ	M
System  arr with a system  arr w	SSH direct to serial ports	N/A	N.	R	<b>L</b>	N.	N

Figure 3. System: Services screen.

Step 4: Configure serial and network devices.

• Select "Serial & Network: Serial Port," which will display the label, mode, and protocol options currently set for the serial port. By default, all the serial ports, except Port 1, are set to console server mode (see the user's manual for other modes).

	BOX	•	System Name Uptime: 0 daj	ACSdoc Model: s, 0 hours, 52 mir	LES1216A Firm hs, 27 secs Cur	nware: 2.8.0u2 rent User: root	Backup Log Out
					Serial &	& Network:	Serial Port
Serial & Network Serial Port Users & Groups Authentication Network Hosts Trusted Networks Cascaded Ports UPS Connections RPC Connections Environmental	Port #	Label	Ports 1-8 F Mode	<sup>2</sup> orts 9-16 Logging Level	Parameters	Flow Control	
	1	Port 1	Console (Unconfigured)	0	9600-8-N-1	None	Edit
	2	Port 2	Console (Unconfigured)	0	9600-8-N-1	None	Edit
	3	Port 3	Console (Unconfigured)	0	9600-8-N-1	None	Edit

Figure 4. Serial & Network: Serial Port screen.

- To configure a serial port, click "Edit."
- Configure the common settings (baud rate, parity, data bits, stop bits, and flow control) to match those of the serial device being controlled.
- Select the console server protocols (Telnet, SSH, TCP, and RFC2217) that will be used for the data connection to the serial port.

NOTE: Port 1 is configured by default in Local Console (modem) mode. Use the crossover-pinned DB9F-RJ-45 adapter and UTP cable to connect to a terminal emulator application on your PC's serial COM port. If you plan to use out-of-band (OoB) dial-in access, connect this serial port to an external modem as covered in detail in the user manual.

- Click "Apply."
- To enable access through the Remote Console Manager to a locally networked computer (referred to as a host), select "Serial & Network: Network Hosts" and click "Add Host."

BLACK	BOX	System Name RR3-Jast5083 Model LES1508A Firmware 3.5.3u5 🚵 🚺 🕼 🕼 🕼 🕼 🕼 🕼
		Serial & Network: Network Hosts
Serial & Network 🗉		
* Serial Port * Users & Groups	IP Address/DNS Name	The host's IP Address or DNS name.
* Authentication  Network Hosts * Network Hosts * Trusted Networks * Cascade Ports * UPS Connections * Enviconmental * Enviconmental * Enviconmental * Enviconmental * Enviconmental * Enviconmental * Port Log * Port Log * Auto-Response * SUTT & SMS * SVICT * Setwork * State	Host Name	A descriptive name to identify the host.
	Description/Notes	A brief description of the host.
	Permitted Services	221cp (sh) - 0 2 231cp (shind) - 0 4431cp (hind) - 0 14341cp (nico) - 0 3590(tcp (nic) - 0 5900(tcp (nic) - 0 Permova
System =		© TCP
<ul> <li>Administration</li> <li>SSL Certificates</li> <li>Configuration Backup</li> </ul>		C UDP Port level 0 - Disabled
* Firmware * IP * Date & Time		Add The TCP services available from this host.
Figure 5.	Serial & N	Network: Network Hosts screen.

- Enter the IP address/DNS name of the host.
   Edit the permitted services used for accessing this host, for example, HTTPS (TCP port 443), VNC (TCP port 5900), or add custom TCP or UDP port numbers—only the services specified here are tunneled through to the host. All other services are blocked.
- Specify the level of information to be logged and monitored for each host access.
- Click "Apply."

Step 5: Add new users.

NOTE: We recommend that you set up a new Administrator user (in the admin group with full access privileges) and log in as this new user for all ongoing administration functions (rather than continuing as root).

- For each new user, select "Serial & Network: Users & Groups" and click "Add User."
- Enter a username and enter and confirm a password.
- Select one or multiple group memberships for the user. To grant limited access to the management console, check the "users" group. To grant full access to the management console, check the "admin" group. By default, the user is granted no management console access.
- Nominate the dial-in options for the user and the accessible hosts and accessible ports the user is allowed to access.
- Click "Apply."

BLACK	RVICES	System Name: RR3-les 1508a Model LES 1508A Firmware: 3.5.3u5 Uptime: 1 days, 1 hours, 56 mins, 54 secs Current User: root Backup Leg Out
		Serial & Network: Users & Groups
Serial & Network 🛛	Add a New user	
» Serial Port     » Users & Groups     » Authentication	Username	A unique name for the user.
Trusted Networks     Call Home     Cascaded Ports	Description	A brief description of the user's role.
» UPS Connections » RPC Connections » Environmental » Managed Devices	Groups	admin (Provides users with unlimited configuration and management privileges) pptpd (Group to allow access to the PPTP VPN server - Users in this group will have their password stored in clear text.)
Alerts & Logging = > Port Log > Auto-Response > SMTP & SMS > SNMP		solaria (clough to allow dallin access via moomen - users in this group win have their password stred in clear they far access and file access to storage devices) prinkell (coupt to at default affect to prinkel) users (Provides users with basic management privileges)
System =		A group with predefined privileges the user will belong to.
Administration     SSL Certificates     Configuration Backup     Firmware     IP     Date & Time     Dial	Password	The users authentication secret. Note: A password may not be required if remote authentication is being used.
	Confirm	Re-enter the users password for confirmation.
<ul> <li>» Firewall</li> <li>» Senvices</li> <li>» Nagios</li> <li>» Configure Dashboard</li> </ul>	SSH Authorized Keys	
Status   Port Access Active Users Statistics Support Report Systog UPS Status		Paste the public keys of authorized public/private keypairs to allow pass-key authentication for this user This is more secure than password based authentication
	Disable Password Authentication	Check to only allow public key authentication for this user when using SSH
<ul> <li>Environmental Status</li> <li>Dashboard</li> </ul>		
- Dashooard	Dial-in Options	
Manage ©  Devices  PortLogs PortLogs Power Power Terminal	Enable Dial-Back	Allow an out-going connection to be triggered by logging into this port.
	Dial-Back Phone Number	The phone number to call-back when user logs in.
	Accessible Host(s)	
	No hosts currently confi	gured.

Figure 6. Serial & Network: Users & Groups screen.

NOTE: The Remote Console Manager comes with a default certificate for initial configuration purposes only. You will need to direct your browser to (temporarily) proceed and accept this untrusted certificate. It is recommended as soon as possible thereafter you generate and install a new trusted certificate. To produce the unique CSR and later upload the newly issued certificate, select System: SSL Certificates.

Step 6: Establish connection to the cellular carrier.

BLACK	<b>BOX</b> RVICES		System Name: Ies1308a Model: LES130 Uptime: 0 days, 3 hours, 26 mins, 59 so	8A Firmware: 3.5.3u5 cs Current User: root	Backup Log Out
				s	ystem: Dial
Serial & Network	Serial DBS	9 Port	Internal Modern	Internal Cellul	ar Modern
* Serial Port * Users & Groups * Authentication * Network Hosts * Trusted Networks * IPsec VPN * Call Home * Call Home * Cascaded Ports * UPS Connections * RPC Connections * Environmental	Internal Cellular M	lodem Dial Sett	ings		
	Disable Dial	Disable mod	dem communication.		
	Enable Dial-In	C Allow incomi	ing modem communication.		
	Enable Dial-Out	C Allow outgoin	ng modem communication.		

Figure 7. System: Dial screen.

- Select "Internal Cellular Modem" on the "System: Dial" menu and check "Enable Dial-Out."
- Enter the carrier's APN e.g. for AT&T (USA) simply enter "i2gold", for T-Mobile (USA) enter "epc.tmobile.com", for InterNode (Aust) enter "internode" and for Telstra (Aust) enter "telstra.internet."

NOTE: Your GSM cellular carrier may have provided you with connection details. However, you generally will only need to enter your provider's APN and leave the other fields blank. If provided a Pin Code you may need to use it to unlock the SIM card.

NOTE: You may also need to use alternate DNS servers from those provided by your carrier. To enable, check Enable Override DNS, then check the Override returned DNS Servers box and enter the IP of the DNS servers into the spaces provided.

- Check "Apply" and a radio connection will be established with your cellular carrier. Out-of-band access is enabled, so the cellular modem connection is always ON.
- Select "Status: Statistics" and verify the Connection Status in the "Failover& Out-of-Band" page is shown as Connected. You can also check your allocated IP address.
- Measure the received signal strength RSSI from the "Cellular Statistics" page.

	BOX RVICES	System Name: Ies1308a: Model LES1308A Firmware: 35.3u5 Uptime: 3 days, 3 hours, 46 mins, 33 accs Current User: root Deship: Log Out
		Status: Statistics
Serial & Network 🗉		
» Serial Port     » Users & Groups     » Authentication     » Network Hosts     » Trusted Networks     » IPsec VPN     • Opser/IPN	Interfaces Routes/DNS	S Serial Ports IP ICMP TCP UDP Failover & Cellular
	Internal Cellular Mod	lem
» Call Home	Model	MC8795V
* UPS Connections	Technology	GSMUMTS
* Environmental	Hardware Version	1.0
* Managed Devices	Firmware Version	K2_0_7_46CAP C:/WS/FW/K2_0_7_46
Alerts & Logging 📃	Boot Version	K2_0_7_40BT C:WS/FW/K2_0_7_40B
» Port Log » Alerts	IMEI	355310036280067
* SMTP & SMS	Serial #	C9A196224431009
System -	Preferred System Mode	AUTO
<ul> <li>Administration</li> <li>SSL Certificates</li> </ul>	Supported System Modes	WCDMA_GSM_AU_2, WCDMA_GSM_AU_3, GSM_ALL, WCDMA_ALL, AUTO

Figure 8. Status: Statistics screen.

NOTE: An RSSI of -99 dbm to –90 dbm is Weak Coverage, -89 dbm to – 70 dbm is Medium, and -69 dbm or greater is Strong

Step 7: Out of band access.

To directly access the Remote Console Manager, it needs to have a Public IP address and it must not have SSH access firewalled. Almost all carriers and cellular service providers offer corporate mobile data service/plans with a Public (static or dynamic) IP address. These plans often have a service fee attached.

- If you have a static public IP address plan, you can directly access the Remote Console Manager using the public IP Address provided by the carrier. However, by default, only HTTPS and SSH access is enabled on the OOB connection. So, you can browse to the Remote Console Manager, but you cannot ping it.
- If you have a dynamic Public IP address plan, then a DDNS service will need to be configured (see the user's manual for details). Once this is done, you can then access the Remote Console Manager using the allocated domain name.

NOTE: By default, most providers offer a consumer grade service that provides dynamic Private IP address assignments to 3G devices. This Private IP address is not visible across the Internet, but generally it is adequate for home and general business use. If you have such a plan, the Failover & Out-of-Band tab on the Status: Statistics page, will show your carrier allocated a Private IP Address (in the range 10.0.x.x, 172.16.x.x or 192.168.x.x). For an inbound OOB connection with such a plan, you will need to set up a VPN (see the user's manual for details).

NOTE: In out-of-band access mode, the internal cellular modem will continually stay connected. The alternative is to set up Failover mode. This will tell the internal cellular connection to remain idle in a low power state. If the primary and secondary probe addresses are not available, it will bring up the cellular connection and connect back to the cellular carrier (see the user's manual for details).

Step 8: Advanced configurations.

The Remote Console Manager offers many more advanced functions including:

 The Alerts & Logging: Auto Response facility monitors serial ports, hosts, user logins, UPSs (uninterruptible power supplies), and RPCs (remote power controllers such as PDUs and IPMI devices). A broad selection of trigger events (such as data patterns, temperature, or battery levels) can be specified. When triggered, a warning e-mail, SMS, Nagios®, or SNMP alert can be sent to a nominated destination or a user defined local response sequence can be initiated (such as power cycling a device).

- Extensive management of UPSs and RPCs using Open Source NUT and Powerman tools. The "Manage: Power" facility enables both administrators and regular users to monitor and control attached PDU power strips, and servers with embedded IPMI BMCs.
- Historical logs of all communications with serial and network-attached devices, system activity, UPS and PDU power status, environmental status, etc. The level of logging is set as ports and devices are configured. Alerts & Logging: Port Log allows this history to be saved locally or remotely. Logs can be viewed from the Status and Manage menus.
- Other advanced features, such as serial port cascading, remote authentication, trusted networks, secure tunneling, Nagios distributed monitoring, and the command line interface are covered in detail in the user manual.

To download the user manual from the Web site:

- 1. Go to www.blackbox.com
- 2. Enter the product code (LES1204A-3G-R2) in the search box:
- 3. Click on the "Resources" tab on the product page, and select the document you wish to download.



Tech support the way it should be.



Great tech support is just 60 seconds away at 724-746-5500 or blackbox.com.



## About Black Box

Black Box provides an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live, 24/7 Tech Support available in 60 seconds or less.

© Copyright 2014. Black Box Corporation. All rights reserved. Black Box® and the Double Diamond logo are registered trademarks of BB Technologies, Inc. Any third-party trademarks appearing in this manual are acknowledged to be the property of their respective owners.

724-746-5500 | blackbox.com

LES1204A-3G-R2 QSG, rev. 6