


LanXPLOER PRO




Quick Reference Guide.



- AA batteries cannot be charged internally.
- Use the RESET button to reset the tester.
- Do not remove the battery to reset.


* Charger LED	Status
Green	Battery is charged
Off (with charger connected)	Battery is not being charged
Green Flashing	Battery cannot be charged — temperature is too high
Red Flashing	22 dBm

Battery Access




Four Ways to Navigate


1




2




3




4




Cable Testing




Network Testing over Copper




In-Line Testing over Copper




Network Testing over Fibre



Network Testing over Wi-Fi



Result Saving and Viewing



LanXPLOER PRO

Visit www.blackbox.co.uk/goto/lanXPLOER for more info.



Black Box Network Services (UK) Ltd.

464 Basingstoke Road, Reading, Berkshire. RG2 0BG

Sales: 0118 965 6000 | Tech: 0118 965 6000 | www.blackbox.co.uk